ULTRA JC-PAD CLEANING/MAINTENANCE DIAMOND PAD

PRODUCT DESCRIPTION

The Ultra XC Diamond Pad is a floor cleaning and restoration polyester pad infused with billions of microscopic diamonds for optimal floor cleaning. With a 7,500 grit grade, the ULTRA XC-PAD is safe to use on your floors.

The ULTRA XC-PAD is perfect for hard and resilient floor surfaces protected with floor finish and factory coated floors. This includes Nóra floors, luxury vinyl floors (LVT), rubber floors, linoleum floors, marmoleum floors, etc.

PROPERTIES

PROPERTY	VALUE
Thickness	1 in (26 mm)
Weight	30 osy 1017 gsm
Fiber Type	Recycled
Size	20″ (520 mm)
Life Cycle	330,000 sq/ft (applying recommended product care instructions)
Abrasive Application	Spray
Abrasive	Industrial Diamond Grit
Color	Gray/Purple
Pack	2 per case

Hoor Care

ULTRACHEMLABS



^{*}Ultra Chem Labs awards its internal Environmentally Sustainable Seal to products that meet third party environmental criteria regarding reduced toxicity, biodegradability, packaging and other characteristics focused on creating a more sustainable environment.

PRODUCT USE

For better results use the pad with Ultra's Cleaner and Conditioner to remove everyday debris, black heel marks and light scratches from resilienwt and hard floors (coated or uncoated). Use with floor machines or auto-scrubbers with speeds up to 350RMP.

ENVIRONMENTALLY CONSCIOUS CONSTRUCTION

The ULTRA XC-PAD is made of 100% recycled polyester, post consumer and industrial recycled waste products and is impregnated with billions of microscopic diamonds.

DIRECTIONS FOR USE

Daily Floor Maintenance (as needed)

- 1. Dust mop or vacuum the floor to remove dust and dirt.
- 2. Damp mop or auto scrub the floor using the Ultra XC-PAD with Cleaner and Conditioner diluted at $\frac{1}{2}$ oz per gallon.
- 3. To restore the floor gloss, burnish the cleaned floor with the Ultra X Diamond Burnishing Pad.

Notes: Mopping with microfiber mops promotes better dirt removal. Only burnish as needed.



Note: Due to the intrinsic properties of the material and variable conditions of use, there may be slight variations in the specifications and results. Please contact us with any questions or concerns.

Hoor Care



PRODUCT CARE

For continued good results, it is important to clean your pads thoroughly by rinsing them off with water. This removes dirt that can wear on the floor and reduce the life of the ULTRA XC-PAD.

FOR MORE INFORMATION CALL: 909-605-1640 EMAIL: CS@ULTRACHEMLABS.COM WWW.ULTRACHEMLABS.COM

ULTRA CHEM LABS CORP 4581 BRICKELL PRIVADO ONTARIO, CA 91761 UNITED STATES